
CD RECEIVER

KDC-8007/8008/9050R

SERVICE MANUAL

KENWOOD


© 1997-2 PRINTED IN JAPAN B51-7127-00 (N) 3610




Extension cord for service (W05-0618-00) 22P

Photo is KDC-8007. K1=KDC-8007, M2=KDC-8008, E1=KDC-9050R

BLOCK DIAGRAM: MECHANISM



BLOCK DIAGRAM: UNIT



CIRCUIT DESCRIPTION

 $\textbf{Microprocessor}: \mu \textbf{PD178016GC} \text{ (IC1, X25-)}$

Terminal description

No.	Pin name	I/O	Port name	Function	Active
1	ANI0	1	NOISE	FM noise detection analog input.	
2	ANI1		SMETER	FM S-meter detection analog input.	
3	ANI2		VALET (K, M)	Valet/demonstration input.	< 1V : Valet, > 4V : Demonstration
	AINIZ	'	PHONE (E)	Phone/Navigation muting input.	< 1V : Phone, > 4V : Navigation muting
4	P13	I	SRM SW1	Position detection input 1 from SRM.	"H" : ON
5	P14	0	MOTOR	Motor control output.	"H" : Loading, "L" : Eject
6	P15	1/0	LO/EJ	Loading/Ejection switching output.	"L" : Loading, "H" : Eject, Input : Stop
7	SI1	I	L DATAL	Data input from LCD driver.	
8	SO1	0	L DATAS	Data output to LCD driver.	
9	SCK1	0	L CLK	Clock output to LCD driver.	
10	P23	0	L CE	CE output to LCD driver.	
11	P24	0	LINH	Reset output to LCD driver.	"L" : RESET
12	SI0	ı	DATA C	Data input from changer.	
13	SO0	0	DATA H	Data output to changer.	
14	SCK0	1	CH CLK	Clock input from changer.	
15	P132	0	M CS	Handshake request to CD mechanism controller.	"L" : Requested
16	P33	0	NC	Not used.	
17	P33	0	IFC	AM IF count control output.	"L" : ON
18	P40	1	CD SW1	Loading detection switch.	"L ": ON
19	P41	1	CD SW2	12cm disc detection switch.	"L ": 12cm disc ON
20	P42	1	CD SW3	Down and Limit switch.	"L" : Chucking
21	GND	-	GND	GND.	
22	VDD	-	VDD	5V.	
23	P43	1	QUAL	RDS reception quality.	
24	P44	1	R DATA	RDS data input.	
25	P45	1	NC	Not used.	
26	P46	1	NC	Not used.	
27	P47	1	FM MUTE	Band muting detection input.	"L" : Station detected
28	AMIFC	_	AM IFC	AM IF count input.	
29	FMIFC	_	FM IFC	FM IF count input.	
30	VDDPLL	_	VDD	5V.	
31	VCOH	_	FM IN	FM OSC input.	
32	VCOL	_	AM IN	AM OSC input.	
33	GNDPLL	-	GND	GND.	
34	EO0	-	EO0	PLL error output 0.	
35	EO1	_	EO1	PLL error output 1.	
36	IC (VPP)	-	VPP	GND.	
37	P50	0	LPF (E)	Low-pass filter switching output.	"L" : ON
38	P51	0	AFC	AFC output.	"L": ON
39	P52	0	SRM SUB-	Storage motor driver control terminal.	
40	P53	0	SRM SUB+	Storage motor driver control terminal.	

CIRCUIT DESCRIPTION

No.	Pin name	I/O	Port name	Function	Active
41	P54	ı	AF SD	AM station detection input.	"H" : Sation detected
40	P55		ANT CONT	Antenna control output.	"H": ON
42	F55	0	LOCAL (E)	Local output.	"H": ON
43	P56	0	FM+B	FM power supply output.	"H": ON
44	P57	0	AM+B	AM power supply output.	"H" : ON
45	P60	0	SCK	Clock output to electronic volume.	
46	P61	1/0	SDA	Data input/output to/from electronic volume.	
47	P62	0	MUTE	Muting output.	"H" : Mute ON
48	P63		CRSC (K, M)	CRSC output.	"H": ON
40	F03	0	AF MUTE (E)	AF muting output.	"L" : ON
49	P64	0	P STBY	Power amp standby output.	"H": ON
50	P65	ı	ACC	ACC detection input.	"L" : ON
51	P66	1	BU DET	Momentary power-down detection input.	"H" : Power-down
52	P67	0	TEST	High temperature protection circuit operation inhibition output.	"H" : Test mode
53	P30	0	P CON	Power control output.	"H": ON
54	P31	0	PON	μ-com and surrounding power control output.	"H": ON
55	P32	0	ILL ON	Illumination output.	"H": Lit
56	P33	0	CH CON2	Changer 2 control output.	"H" : CH2 ON
57	P34	0	CH CON1	Changer 1 control output.	"H" : CH1 ON
58	P35	0	REQ H	Handshake request to changers.	"L" : Request
59	BUZ	0	BEEP	Beep output.	
60	P37	ı	E2DTI	Data input from E2PROM.	
61	P120	0	E2CE	CS output to E2PROM.	
62	P121	0	MCLK/E2CK	Clock output to CD mechanism controller/E2PROM.	
63	P122	ı	DATA M	Data input from CD mechanism controller.	
64	P123	0	DATA S/E2DIO	Data output to CD mechanism controller.	
65	P124	1	SRM SW2	Position detection input 2 from SRM.	"L" : ON
66	P125	1	SRM DET	Storage mechanism detection.	"L" : SRM detected
67	INTP0	1	REMO	Remote control signal input.	: Request
68	INTP1	1	R CLK	RDS clock input.	
69	INTP2	1	REQ C	Handshake request from changer.	"L" : Request
70	INTP3	0	M RST	Reset output to CD mechanism controller.	"L" : Reset
71	P04	1	M MUTE	Muting request from CD mechanism controller.	"L" : Request
72	P05	1	M SRQ	Handshake request from CD mechanism controller.	Request
73	P06	0	M STOP	Stop request to CD mechanism controller.	"L" : Request
74	CPUREQ	_	VDD	5V.	
75	GND	_	GND	GND.	
76	X2	_	X2	X'tal oscillator connection.	
77	X1	-	X1	X'tal oscillator connection.	
78	OSCREG	-	VDD	Oscillator power supply.	The second secon
79	VDD	-	VDD	Power voltage application terminal.	
80	RESET	_	RESET	Reset input.	

ADJUSTMENT


No.	ITEM	INPUT SETTING	OUTPUT SETTING	TUNER (RECEIVER)	ALIGNMENT POINTS	ALING FOR	FIG.
FIV	section						
1	DISCRIMINATOR	(A) 98.1MHz Odev 60dBµ (ANT input)	Connect a DC voltmeter to CN8.	FM 98.1MHz	T1	0V	(a)
2	ANRC	* (C) 98.1MHz 1kHz, ±67kHz dev Pilot: ±7.5kHz dev Selector: L or R 35dBµ (ANT input)	(B)	FM 98.1MHz	VR1	Separation 10dB	

*KDC-9050R

(C)


98.1MHz

1kHz, ±40kHz dev Pilot : ±6kHz dev



PC BOARD (COMPONENT SIDE VIEW)

ELECTRIC UNIT: X25-781X-XX (8007: 0-11, 8008: 0-22, 9050R: 2-71)




(X25-781X-XX)

IC	1	2	3	4	5	6	7	8	9	10	11	12	13	14
address	4C	4E	3C	2E	4D	5B	4C	4B	5D	3D	3D	5F	5E	4F


Q	1	2	3	4	5	6	7	8	9	10	11	12	13	14	17	18	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36
address	3B	3B	3C	3C	5B	3C	4C	3B	5B	5C	5B	5B	5B	5B	5F	5F	4B	4B	4C	3B	4B	4C	4B	4B	3F	2F	2F	2F	3F	2F	3C	2E


100	Q	-	-	-			-		-																								
- 1	address	3C	5E	4C	4C	3E	3E	5D	4D	4D	4E	3E	4E	4E	3D	3D	3D	3D	3F	3F	4E	4E	4E	3G	3F	4E	3F	3F	4F	4F	4F	4F	4F

SWITCH UNIT: X13-9052-70




CD PLAYER UNIT: X32-4290-00






SWITCH UNIT: X13-9052-70



CD PLAYER UNIT: X32-4290-00



(X13-9052-70)


-	IC	Q	address
- Contraction of the last	1		2M
-	2		2K
-	3		2J
		1	2M
		2	2J
		3	2L
		4	2L


(X32-4290-00)

IC	Q	address
1		4J
2		5J
3		6K
4		6M
5		5J
6		5K
	1	4K
	2	6K
	3	5K
	5	6J
	6	5K

Refer to the schematic diagram for the values of resistors and capacitors.


74 75 76 77 78 79 80 82 83 84 85 86 4E 4E 3G 3F 4E 3F 3F 4F 4F 4F 4F





AD

ΑB




AJ


AN

AF

AH



SWITCH UNIT: X13-9052-70




(X13-9052-70)


IC	Q	address
1		2AV
2		2AX
3		2AY
	1	2AV
	2	2AY
	3	2AW
	4	2AW

(X32-4290-00)

IC	Q	address
1		4AY
2		5AY
3		6AX
4		6AV
5		5AY
6		5AX
	1	4AX
	2	6AX
	3	5AX
	5	6AY
	6	5AX



Refer to the schematic diagram for the values of resistors and capacitors.




(X25-781X-XX)


10	1	2	3	4	5	р	1	8	9	10	11	12	13
address	4BF	4BD	3BF	2BD	4BE	5BG	4BF	4BG	5BE	3BE	3BE	5BC	5BD
		1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1											

	Q	1	2	3	4	5	6	7	8 9	10	11	12	
a	ddress	3BG	3BG	3BF	3BF	5BG	3BF	4BF	3BG 5BG	5BF	5BG	5BG	5


Q	37	38	39	40	41	42	50	51	52	53	60	61	
address	3BF	5BD	4BF	4BF	3BD	3BD	5BE	4BE	4BE	4BD	3BD	4BD	4







ELECTRIC UNIT: X25-781X-XX (8007: 0-11, 8008: 0-22, 9050R: 2-71)




(X25-781X-XX)

 IC
 1
 2
 3
 4
 5
 6
 7
 8
 9
 10
 11
 12
 13
 14

 address
 4BF
 4BD
 3BF
 2BD
 4BE
 5BG
 4BF
 4BG
 5BE
 3BE
 3BE
 5BC
 5BD
 4BC

Q 1 2 3 4 5 6 7 8 9 10 11 12 13 14 17 18 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 address 3BG 3BF 3BF 5BG 3BF 4BF 3BG 5BG 5BG 5BG 5BG 5BG 5BG 5BC 5BC 4BG 4BG 4BF 3BG 4BG 4BG 4BG 4BG 3BC 2BC 2BC 2BC 3BC 2BC 3BC 2BC 3BF 2BD



BW


CAUTION: For continued safety, replace safety critical components only with manufacturer's recommended parts (refer to parts list). △ Indicates safety critical components. For continued protection against risk of fire, replace only with same type and rating fuse (s). To reduce the risk of electric shock, leakage-current or resistance measurements shall be carried out (exposed parts are acceptably insulated from the supply circuit) before the appliance is returned to the customer.

• The DC voltage is an actual reading measured with a high impedance type voltmeter. The measurement value may vary depending on the measuring instruments used or on the product.

BS

BU

KDC-8007/9050R KENWOOD




CAUTION: For continued safety, replace safety critical components only with manufacturer's recommended parts (refer to parts list).

△ Indicates safety critical components. For continued protection against risk of fire, replace only with same type and rating fuse (s). To reduce the risk of electric shock, leakage-current or resistance measurements shall be carried out (exposed parts are acceptably insulated from the supply circuit) before the appliance is returned to the customer.


• The DC voltage is an actual reading measured with a high impedance type voltmeter. The measurement value may vary depending on the measuring instruments used or on the product.

KDC-8007/9050R KENWOOD

EXPLODED VIEW (MECHANISM)



EXPLODED VIEW (UNIT)



PARTS LIST

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnes dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

KDC-8007/8008/9050R

Ref No. Parts No. Description		Parts No.	Description/Destination	Ref No.			Parts No.	Description/Destination
		KDC-800	7/8008/9050R	Δ	F1	2 D	F52-0006-05	FUSE(MINI BLADE TYPE)
202 1D 203 2D 204 1C 205 1D 206 1D		A10-4308-02 A10-4315-04 A10-4317-04 A10-4319-04 A10-4321-04	CHASSIS ASSY CHASSIS CALKING ASSY CHASSIS CALKING ASSY CHASSIS CALKING ASSY CHASSIS CALKING ASSY		257 258 259 260 261	1 D 1 D 1 D 1 D 1 D	G01-2816-04 G01-2817-04 G01-2818-04 G01-2819-04 G01-2820-04	TORSION COIL SPRING TORSION COIL SPRING EXTENSION SPRING TORSION COIL SPRING TORSION COIL SPRING
207 1D 210 3C 212 2C 213 1D PA1 3C PA1 3C PA1 3C RM1 1C	*	A10-4353-03 A22-1293-03 A46-1260-02 A52-0710-02 A64-1042-02 A64-1045-02 A64-1047-02 A70-0860-05	CHASSIS ASSY SUB PANEL ASSY REAR COVER TOP PLATE PANEL ASSY (KDC-8007) PANEL ASSY (KDC-8008) PANEL ASSY (KDC-9050R) REMOTE CONTROLLER ASSY(9050R)		262	1 D	G11-1733-04 H10-4560-02 H13-1681-04 H25-0329-04 H25-0337-04 H25-1108-04 H25-1111-04	CUSHION POLYSTYRENE FOAMED FIXTURE CARTON BOARD PROTECTION BAG(280X450X0.03) K1M2 PROTECTION BAG(180X300X0.03) PROTECTION BAG(100X300X0.03) M2E1 PROTECTION BAG(280X450X0.03) E1
220 2C 221 1C 222 3C 223 3C 223 3C 223 3C		B03-3021-04 B07-2087-02 B07-2096-02 B10-1754-01 B10-1757-01	DRESSING SEAL ESCUTCHEON ESCUTCHEON FRONT GLASS FRONT GLASS		265 266 267 268	1C 1C 1C	H54-0786-04 H54-0789-04 H54-0791-04 J19-4720-04 J19-4721-04 J21-7630-33 J21-7768-04	ITEM CARTON CASE K1 ITEM CARTON CASE M2 ITEM CARTON CASE E1 BRACKET K1M2 BRACKET K1M2 MOUNTING HARDWARE ASSY MOUNTING HARDWARE ASSY
-		B46-0100-50 B46-0172-13 B46-0612-14 B64-0979-00 B64-0980-00 B64-0981-00 B64-0982-00	WARRANTY CARD QUESTIONAIRE CARD ID CARD INST.MANUAL(ENG,FRE) INST.MANUAL(SPA) INST.MANUAL(ENG,CHI) INST.MANUAL(ENG,FRE)		270 271 272 FPC1 FPC2 FPC3	1 D 1 C 3 D 1 D 2 C	J31-1035-04 J54-0606-04 J84-0061-03 J84-0062-03 J84-0066-03	MOUNTING HARDWARE COLLAR STAY K1M2 FLEXIBLE PRINTED WIRING BOARD FLEXIBLE PRINTED WIRING BOARD FLEXIBLE PRINTED WIRING BOARD
- - 225 10		B64-0983-00 B64-0984-00 B64-0985-00 D10-4067-04	INST.MANUAL(GER,ITA) INST.MANUAL(DUT,P@R) INST.MANUAL(SPA) LEVER		275 276 277 278 279	3C 3C 3C 3C 3C	K24-1767-04 K25-0794-03 K25-0795-03 K25-0796-03 K25-0798-03	KNOB(RESET) KNOB(VOL.) KNOB(PRESET) KNOB(FM,AM) KNOB(CD,CH)
230 1D 231 1D 232 1D 233 1D 234 1D		D10-4135-04 D10-4136-04 D13-1302-04 D13-1306-04 D13-1307-03	ARM ASSY ARM ASSY GEAR ASSY GEAR		280 281 282 283 A	3C 3C 1C 1C 3D	K25-0799-03 K25-0803-03 N09-1885-05 N99-1622-05 N83-3005-46	KNOB(CLK) KNOB(AUD) SEMS (MACHINE SCREW) E1 SCREW SET KIM2 PAN HEAD TAPTITE SCREW
235 1D 236 1D 239 1D 240 1D		D13-1308-04 D13-1309-04 D13-1312-04 D13-1313-04	GEAR GEAR GEAR GEAR		сво ошн	2C 3C 1D 3C	N67-3005-46 N30-2003-46 N09-4184-05 N80-2005-46	PAN HEAD SEMS SCREW PAN HEAD MACHINE SCREW MACHINE SCREW (M2X2 25270703) PAN HEAD TAPTITE SCREW
242 1D 243 1D 244 1D 246 1D 247 3D	1 3	D13-1315-04 D13-1320-03 D13-1321-03 D14-0678-04 D14-0680-04	GEAR GEAR ASSY GEAR ASSY ROLLER ASSY ROLLER		F G H J K	2D 1D 3C 1D	N80-2008-46 N88-2006-45 N35-2003-45 N19-2062-04 N19-2022-04	PAN HEAD TAPTITE SCREW FLAT HEAD TAPTITE SCREW BINDING HEAD MACHINE SCREW FLAT WASHER FLAT WASHER
248 3D 250 2D 251 2D DC1 1C		D14-0681-04 E30-4447-05 E30-4448-05 E30-4435-05	ROLLER CORD WITH PINPLUG(RCA) CORD WITH DIN CONNECTOR(CH) DC CORD		M Q R S1	3D 1D 1D	N35-2004-46 N19-2058-04 N19-2094-04 S68-0822-05	BINDING HEAD MACHINE SCREW FLAT WASHER FLAT WASHER PUSH SWITCH
DC2 1C 252 1D 255 2D		E30-4437-05 F09-1244-04 F29-0049-05	DC CORD SHEET INSULATING COVER		284 M1	1 C 1 D	T90-0512-05 T42-0752-04	ANTENNA ADAPTOR E1

K1: KDC-8007

M2: KDC-8008

E1: KDC-9050R

PARTS LIST

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

KDC-8007/8008/9050R SWITCH UNIT (X13-9052-70) ELECTRIC UNIT (X25-781X-XX)

Ref No.	N e v	Parts No.	Description/Destination	A
ME1 20	;	X92-3190-00	MECHANISM ASSY	C1
		SWITCH UN	NT (X13-9052-70)	C1 C1
D1 -9 LCD1 20 PL1 -4		B30-1349-05 B38-0671-05 B30-1478-05	LED LIQUID CRYSTAL LAMP (5.5V .125A)	C1 C1
C1 C2 ,3 C4 C5		CK73FB1H821K CK73FB1H473KTA CK73FB1H103K C92-0509-05 CK73FB1H103K	CHIP C 820PF K CHIP C 0.047UF K CHIP C 0.010UF K CHIP-TAN 10UF 6.3WV CHIP C 0.010UF K	C1 C2 C2 C2 C2
07 08 ,9 010		CK73FB1H821K CK73FB1H473KTA CK73FB1H103K	CHIP C 820PF K CHIP C 0.047UF K CHIP C 0.010UF K	C2 C2 C2 C2 C3
303 CN1		E29-1520-04 E40-9407-05	CONDUCTIVE RUBBER FLAT CABLE CONNECTOR	C3
.1 ,2		L40-4795-34	SMALL FIXED INDUCTOR	C3
CP1 CP2 R8 R9		R90-1016-05 R90-0725-05 RK73FB2A683J RK73FB2A472J	MULTIPLE RESISTOR MULTI-COMP 1K X2 CHIP R 68K J 1/10W CHIP R 4.7K J 1/10W	C3 C3 C3
R10 R11 R12		RK73FB2A101J RK73FB2A683J RK73FB2A473J	CHIP R 100 J 1/10W CHIP R 68K J 1/10W CHIP R 47K J 1/10W	C4 C4 C4
R13 -15 R16 -19 R20		RK73EB2B331J RK73EB2B471J RK73EB2B331J	CHIP R 330 J 1/8W CHIP R 470 J 1/8W CHIP R 330 J 1/8W	C4 C4 C4
R21 -24 R25 ,26		RK73EB2B130J RK73FB2A273J	CHIP R 13 J 1/8W CHIP R 27K J 1/10W	C 4 C 4
51 -4 56 -11 512 -21 522		\$70-0839-05 \$70-0839-05 \$70-0813-05 \$40-1601-15	TACT SWITCH TACT SWITCH TACT SWITCH PUSH SWITCH	C4 C5 C5
CC1 CC2 CC3 P1 , 2		LC75853NE LC75833E PAS-B06B1FE DTA114EK UN2111	MOS-IC MOS-IC ANALOGUE IC DIGITAL TRANSISTOR DIGITAL TRANSISTOR	C5 C5 C5 C5
3 , 4		2SD2114K	TRANSISTOR	C5 C5
. 1	$\overline{}$		IIT (X25-781X-XX)	C6
1 2 3 4 5		C90-2822-05 CK73FB1H103K CE04CW1C101M CK73FB1H103K C90-2594-05	ELECTR0 3900UF 16WV CHIP C 0.010UF K ELECTR0 100UF 16WV CHIP C 0.010UF K ELECTR0 10UF 10WV	C6 C6
6 7 8 9		CE04CW0J101M CK73FB1H102K CE04CW1A221M CE04CW1A101M CK73EB1C225K	ELECTRO 100UF 6.3WV CHIP C 1000PF K ELECTRO 220UF 10WV ELECTRO 100UF 10WV CHIP C 2.2UF K	C7 C7 C7
11 12 ,13		C90-2595-05 CK73EB1C225K	ELECTRO 4.7UF 16WV CHIP C 2.2UF K	C7 C7

			K1:0-11	M2:0-2	2 E1	: 2-7
Ref No.	N e w	Parts No.	Desc	ription/Des	tination	
C14 C15 C16 C17 C18		CK73FB1H223KTA C90-2840-05 CE04CW1C220M CE04CW1E100M CK73FB1H103K	CHIP C ELECTRO ELECTRO ELECTRO CHIP C	0.022UF 100UF 22UF 10UF 0.010UF	K 16WV 16WV 25WV	
C19 C20 C21 C22 C23		CE04CW1C101M CK73FB1H103K C90-2602-05 CK73FB1E683KTA C90-2598-05	ELECTRO CHIP C ELECTRO CHIP C ELECTRO	100UF 0.010UF 0.10UF 0.068UF 3.3UF	16WV K 50WV K 25WV	
C24 C25 ,26 C27 C28 ,29 C30		CK73FB1H102K CK73FB1H103K CK73FB1C104K CC73FCH1H22OJ CK73FB1C104K	CHIP C CHIP C CHIP C CHIP C	1000PF 0.010UF 0.10UF 22PF 0.10UF	K K K J K	
C31 C32 C33 -35 C33 -36 C37 ,38		CK73FB1H223KTA CC73FCH1H331J CK73FB1H103K CK73FB1H103K CK73FB1H103K CE04CW0J470M	CHIP C CHIP C CHIP C CHIP C ELECTRO	0.022UF 330PF 0.010UF 0.010UF 47UF	K J K K 6.3WV	M2 K1E
C39 C39 ,40 C41 ,42 C42 C43		CK73FB1H103K CK73FB1H103K CE04CW1A101M CE04CW1A101M C93-1052-05	CHIP C CHIP C ELECTRO ELECTRO CERAMIC	0.010UF 0.010UF 100UF 100UF 6800PF	K K 10WV 10WV K	K1M2 E1 E1 K1M2 E1
C44 C44 C45 C46 C46		CK73FB1C104K CK73FB1E683KTA C93-1062-05 C90-2525-05 C90-2807-05	CHIP C CHIP C CHIP C NP-ELECT NP-ELEC	0.10UF 0.068UF 0.033UF 2.2UF 0.47UF	K K K 35WV 50WV	K1M3 E1 E1 K1M3 E1
C47 C48 ,49 C50 C51 C52		CK73FB1H103K CK73FB1C104K CK73FB1C224K CK73FB1H103K CK73FB1H223KTA	CHIP C CHIP C CHIP C CHIP C	0.010UF 0.10UF 0.22UF 0.010UF 0.022UF	K K K K	
C53 C54 C55 C56 C57		CK73FB1C224K CK73FB1C104K CK73FB1H103K CF0-2597-05 CK73EB1C225K	CHIP C CHIP C CHIP C ELECTRO CHIP C	0.22UF 0.10UF 0.010UF 10UF 2.2UF	K K K 16WV K	
058 059 060 ,61 062 ,63		CE04CW1C470M CK73FB1E473KTA C90-2595-05 CK73FB1H152K CE04CW1A101M	ELECTRO CHIP C ELECTRO CHIP C ELECTRO	47UF 0.047UF 4.7UF 1500PF 100UF	16WV K 16WV K 10WV	K1M2
065 066 -69 070 ,71 072 ,73		CK73FB1H103K CK73FB1C104K C90-2597-05 CK73FB1H222K C90-2608-05	CHIP C CHIP C ELECTRO CHIP C ELECTRO	0.010UF 0.10UF 10UF 2200PF 1.0UF	K K 16WV K 50WV	
075 075 076 077 077		CK73FB1C104K CK73FB1H103K CK73FB1H102K CK73FB1H223KTA CK73FB1H102K	CHIP C CHIP C CHIP C CHIP C	0.10UF 0.010UF 1000PF 0.022UF 1000PF	K K K K	K1M2 E1
					•	

K1: KDC-8007

M2: KDC-8008

E1: KDC-9050R

PARTS LIST

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnes dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

Ref No.	Parts No.	Descript	tion/Dest	ination			Ref No.	o. Ne Parts No.		Descri	iption/Des	tination	
C79 C80 C81 C82 C83	CK73FB1C154K C90-2608-05 CK73EB1C105K C90-2610-05 CK73FB1H223KTA	ELECTRO 1. CHIP C 1. ELECTRO 2.	.15UF .OUF .OUF .2UF .022UF	K 50WV K 50WV K			C215 C216 C217 C218 C219		CE04CW1A101M CK73FB1H103K CK73FB1C823K CK73FB1H223KTA CE04CW1A330M	ELECTRO CHIP C CHIP C CHIP C ELECTRO	100UF 0.010UF 0.082UF 0.022UF 33UF	10WV K K K 10WV	
C84 C85 C86 C87 C88	C90-2610-05 CC73FCH1H271J CK73FB1E473KTA CK73FB1C823K CK73FB1H272K	CHIP C 27 CHIP C 0. CHIP C 0.	.2UF 70PF .047UF .082UF 700PF	50WV J K K K			C220 C221 C222 C222,223 C223		CK73FB1H103K CE04CW1A101M CK73FB1H103K CK73FB1H103K CK73FB1H102K	CHIP C ELECTRO CHIP C CHIP C CHIP C	0.010UF 100UF 0.010UF 0.010UF 1000PF	K 10 W V K K K	M2E1 K1 E1
C89 C90 C91 C92 ,93 C94	CC73FCH1H120J C90-2594-05 CK73FB1H103K CC73FSL1H122J CC73FCH1H060D	CHIP C 0.	2PF OUF .010UF 200PF .0PF	J 10WV K J D	E1 E1 E1 E1	П	C224 C225 C226 C227 C228		CK73FB1H103K CC73FCH1H820J CC73FCH1H470J CK73FB1H103K C90-2608-05	CHIP C CHIP C CHIP C CHIP C ELECTRO	0.010UF 82PF 47PF 0.010UF 1.0UF	K J K 50WV	E1 E1 E1
C95 C96 C97 C98	CC73FCH1H471J CC73FCH1H820J CK73FB1H223KTA CC73FCH1H121J CC73FSL1H102J	CHIP C 82 CHIP C 0 CHIP C 12	70PF 2PF .022UF 20PF 000PF	J J K J	E1 E1 E1 E1		C229 C229,230 C231 C232 C233		CK73FB1H103K CK73FB1H103K CK73FB1C104K CC73FCH1H181J CK73FB1H103K	CHIP C CHIP C CHIP C CHIP C CHIP C	0.010UF 0.010UF 0.10UF 180PF 0.010UF	K K K J K	K1M2 E1
C100 C101 C102-106 C110 C111,112	CC73FCH1H471J CC73FSL1H222J CK73FB1H103K C90-2595-05 CE04CW0J470M	CHIP C 22 CHIP C 0 ELECTRO 4	70PF 200PF .010UF .7UF 7UF	J J K 16WV 6.3WV	E1 E1		CN1 CN2 CN3 CN4		E23-0732-04 E40-3243-05 E40-3237-05 E40-3252-05 E40-3261-05	TERMINAL PIN ASSY PIN ASSY PIN ASSY PIN ASSY			
C113 C114-121 C122-125 C126 C127	C90-2595-05 CK73FB1C274K CK73EB1C225K C90-2608-05 CE04CW1A330M	CHIP C 0 CHIP C 2 ELECTRO 1	.7UF .27UF .2UF .OUF 3UF	16WV K K 50WV 10WV			CN5 CN6 CN7 CN8 J1		E40-9550-05 E40-9557-05 E40-5029-05 E40-3640-05 E58-0836-05	FLAT CABLE FLAT CABLE FLAT CABLE PIN ASSY RECTANGULA	CONNECT CONNECT	OR OR	
C128 C129-132 C135-140 C143,144 C145-152	CK73FB1H103K C90-2597-05 C90-2597-05 C90-2597-05 CK73FB1H153KTA	ELECTRO 10 ELECTRO 10 ELECTRO 10	.010UF OUF OUF OUF .015UF	K 16WV 16WV 16WV K	E1		WH1 2D CF1 ,2 CF1 ,2 L1 -6 L1 ,2	. :	E30-4452-05 L72-0719-05 L72-0720-05 L40-4795-34 L40-4795-34	CORD WITH CERAMIC FI CERAMIC FI SMALL FIXE SMALL FIXE	LTER LTER ED INDUCT	' © R	K1M2 E1 E1 K1M2
C153 C154 C155-158 C159 C161	C90-2597-05 CE04CW1A101M CK73FB1C224K C90-2608-05 C90-2598-05	ELECTRO 10 CHIP C 0 ELECTRO 1	OUF OOUF .22UF .OUF .3UF	16WV 10WV K 50WV 25WV			L7 L8 L9		L40-4795-34 L40-4791-17 L33-1039-05 L40-2205-34 L30-0730-05	SMALL FIXE SMALL FIXE LINE FILTE SMALL FIXE FM IFT	D INDUCT INDUCT COIL	OR OR(4.7	K1M2 UH,K)
C200,201 C202 C203 C204 C205	CK73FB1H103K CK73FB1H822K CK73FB1H102K CK73FB1H103K C92-0005-05	CHIP C 8: CHIP C 1: CHIP C 0	.010UF 200PF 000PF .010UF .2UF	K K K 6.3WV	E1 E1 E1		X1 X1 X2 X3		L77-1163-05 L77-1165-05 L78-0545-05 L77-2002-05	CRYSTAL RE CRYSTAL RE RESONATOR CRYSTAL RE	SONATOR(
C206 C207 C208 C209 C210	CK73FB1H103K CC73FCH1H331J C90-2597-05 CE04CW1A330M CC73FCH1H561J	CHIP C 3. ELECTRO 1: ELECTRO 3.	.010UF 30PF 0UF 3UF 60PF	K J 16WV 10WV J	E1 E1		A 2D L 2D N 2D P 2D		N83-3005-46 N83-3020-46 N64-3010-46 N30-3005-46	PAN HEAD T PAN HEAD T PAN HEAD S PAN HEAD N	TAPTITE S SEMS SCRE MACHINE S	CREW W CREW	
C211 C212 C213 C214 C214	CK73FB1H223KTA CK73FB1H103K CK73FB1H102K CK73FB1E473KTA CK73FB1H103K	CHIP C 0 CHIP C 1 CHIP C 0	.022UF .010UF 000PF .047UF .010UF	K K K K	K1M2 E1		CP1 CP2 CP3 CP4 -7 R1		R90-0724-05 R90-0725-05 R90-1015-05 R90-0725-05 RK73FB2A223J	MULTI-COME MULTI-COME MULTIPLE F MULTI-COME CHIP R	1K RESISTOR 1K	X4 X2 X2 1/10W	,

K1: KDC-8007

M2: KDC-8008

E1: KDC-9050R

PARTS LIST

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

ELECTRIC UNIT (X25-781X-XX) K1: 0-11 M2: 0-22 E1: 2-71

		irts No. werden nich	T general.				_		-		K1:	0-11	M2	: 0-2	22 E1	: 2-7
Ref No.	N e w	Parts No.	Des	cription	/De	stination		Ref No.	N e	Parts No.		Des	ription	/Des	stinatio	n
R2 R3 R4 R5 R6		RK73FB2A101J RK73EB2B221J R92-2046-05 R92-2039-05 RK73FB2A153J	CHIP R CHIP R CHIP R CHIP R CHIP R	100 220 4.3K 24K 15K	J D D J	1/10W 1/8W 1/10W 1/10W 1/10W		R68 ,69 R71 ,72 R72 R73 R74		RK73FB2A104J RK73FB2A104J RK73FB2A104J RK73FB2A470J RK73FB2A222J	CHIE CHIE CHIE CHIE	P R P R	100K 100K 100K 47 2.2K	J J J	1/10W 1/10W 1/10W 1/10W	/ M2 / K1E1
R7 R8 R9 ,10 R11 R12		RK73FB2A152J RK73FB2A102J RK73FB2A470J RK73FB2A332J RK73FB2A104J	CHIP R CHIP R CHIP R CHIP R CHIP R	1.5K 1.0K 47 3.3K 100K	J J J J	1/10W 1/10W 1/10W 1/10W 1/10W		R76 R78 ,79 R81 R82 R83		RK73FB2A222J RK73FB2A102J RK73EB2B103J RK73EB2B102J RK73EB2B472J	CHIE CHIE CHIE CHIE	R R R	2.2K 1.0K 10K 1.0K 4.7K	J J	1/10W 1/10W 1/8W 1/8W 1/8W	
R15 R16 R17 R18 R19		RK73FB2A104J RK73FB2A102J RK73FB2A272J RK73FB2A563J RK73FB2A103J	CHIP R CHIP R CHIP R CHIP R	100K 1.0K 2.7K 56K 10K	J J J J	1/10W 1/10W 1/10W 1/10W 1/10W		R85 R86 R87 R88 R89		RK73FB2A223J RK73FB2A472J R92-2063-05 RK73FB2A104J RK73FB2A102J	CHIE CHIE CHIE CHIE CHIE	R	22K 4.7K 680 100K 1.0K	J J J J	1/10W 1/10W 1/2W 1/10W	
R20 R21 R22 ,23 R24 R25		RK73FB2A913J RK73FB2A750J RK73FB2A470J RK73FB2A913J RK73FB2A153J	CHIP R CHIP R CHIP R CHIP R	91K 75 47 91K 15K	J J J J	1/10W 1/10W 1/10W 1/10W 1/10W		R90 R91 R92 R93 R94		RK73FB2A470J RK73FB2A223J RK73FB2A104J RK73FB2A102J RK73FB2A223J	CHIP CHIP CHIP CHIP	R R R	47 22K 100K 1.0K 22K	J J J J	1/10W 1/10W 1/10W 1/10W 1/10W	
R26 R28 R29 ,30 R31 R32 ,33		RK73FB2A163J RK73FB2A913J R92-0365-05 RK73FB2A223J RK73FB2A472J	CHIP R CHIP R CHIP R CHIP R	16K 91K 1.0K 22K 4.7K	J J J J	1/10W 1/10W 1/2W 1/10W 1/10W K1	2	R96 R97 R99 R100 R101		RK73FB2A102J RK73FB2A223J RK73FB2A222J RK73FB2A472J RK73FB2A222J	CHIP CHIP CHIP CHIP	R R R	1.0K 22K 2.2K 4.7K 2.2K	J J J J	1/10W 1/10W 1/10W 1/10W 1/10W	
R33 R34 R35 R37 R38		RK73FB2A472J R92-0366-05 RK73FB2A223J RK73FB2A104J RK73FB2A223J	CHIP R CHIP R CHIP R CHIP R CHIP R	4.7K 56C 22K 100K 22K	J J J J	1/10W E1 1W K1 1/10W K1 1/10W 1/10W		R102 R103 R104 R105 R106		RK73FB2A472J RK73FB2A222J RK73FB2A103J RK73FB2A223J RK73FB2A472J	CHIP CHIP CHIP CHIP	R R R	4.7K 2.2K 10K 22K 4.7K	J J J	1/10W 1/10W 1/10W 1/10W 1/10W	
R39 ,40 R41 R42 R43 R44		RK73FB2A123J RK73FB2A562J RK73EB2B473J RK73FB2A622J RK73EB2B473J	CHIP R CHIP R CHIP R CHIP R CHIP R	12K 5.6K 47K 6.2K 47K	J J J J	1/10W 1/10W 1/8W 1/10W 1/8W		R109 R110 R111 R113 R117		RK73FB2A102J RK73FB2A562J RK73FB2A101J RK73FB2A104J RK73FB2A472J	CHIP CHIP CHIP CHIP	R R R	1.0K 5.6K 100 100K 4.7K	J J J	1/10W 1/10W 1/10W 1/10W 1/10W	
R45 R46 R47 R48 R49		RD14DB2H332J RK73FB2A473J RK73FB2A471J RK73FB2A104J RK73FB2A334J	SMALL-RD CHIP R CHIP R CHIP R CHIP R	3.3K 47K 470 100K 330K	J J J J	1/2W 1/10W 1/10W 1/10W 1/10W		R118 R119,120 R123 R124 R130		RK73FB2A222J RK73FB2A104J RK73FB2A163J RK73FB2A183J RK73FB2A680J	CHIP CHIP CHIP CHIP CHIP	R R R	2.2K 100K 16K 18K 68	J J J J	1/10W 1/10W 1/10W 1/10W 1/10W	E1
R50 R51 -53 R54 R55 R56		RK73FB2A104J RK73FB2A102J RK73FB2A222J RK73FB2A102J RK73FB2A104J	CHIP R CHIP R CHIP R CHIP R			1/10W 1/10W 1/10W 1/10W 1/10W E1		R132 R133 R134 R135 R136		RK73FB2A222J RK73FB2A223J RK73FB2A101J RK73FB2A562J RK73FB2A332J	CHIP CHIP CHIP CHIP	R R R	2.2K 22K 100 5.6K 3.3K	J J J	1/10W 1/10W 1/10W 1/10W 1/10W	E1 E1 E1
R56 -58 R57 R58 R59 R60		RK73FB2A104J RK73FB2A223J RK73FB2A473J RK73FB2A102J RK73FB2A103J	CHIP R CHIP R CHIP R CHIP R CHIP R	100K 22K 47K 1.0K 10K	J J J J	1/10W K1M 1/10W E1 1/10W E1 1/10W 1/10W		R137 R137 R138 R139 R139	ļ	RK73FB2A102J RK73FB2A222J RK73FB2A302J RK73FB2A472J RK73FB2A561J	CHIP CHIP CHIP CHIP	R R R	1.0K 2.2K 3.0K 4.7K 560	J J J	1/10W 1/10W 1/10W 1/10W 1/10W	K1M2 E1 E1
R61 -63 R64 R65 R66 R68		RK73FB2A222J RK73FB2A104J RK73FB2A222J RK73FB2A102J RK73FB2A104J	CHIP R CHIP R CHIP R CHIP R CHIP R	2.2K	J	1/10W E1 1/10W 1/10W E1 1/10W 1/10W M2E		R140 R141 R142 R143 R144,145		RK73EB2B751J RK73FB2A331J RK73FB2A331J RK73FB2A104J RK73EB2B104J	CHIP CHIP CHIP CHIP CHIP	R R R	750 330 330 100K 100K	J J J	1/8W 1/10W 1/10W 1/10W 1/8W	K1M2

K1: KDC-8007

M2: KDC-8008

E1: KDC-9050R

PARTS LIST

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnes dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

ELECTRIC UNIT (X25-781X-XX) K1: 0-11 M2: 0-22 E1: 2-71

Ref No.	Parts No.	Description/Destination	Ref No. Parts N	o. Description	/Destination
R146-148 R158 R164,165 R167 R168-170	RK73FB2A222J RK73EB2B472J R92-2104-05 RK73EB2B472J RK73EB2B102J	CHIP R 2.2K J 1/10W CHIP R 4.7K J 1/8W CHIP R 2.2 J 1W CHIP R 4.7K J 1/8W CHIP R 1.0K J 1/8W	R303 RK73FB2A R304 RK73FB2A R305 RK73FB2A R306 RK73FB2A R307,308 RK73EB2B	172J CHIP R 4.7K 222J CHIP R 2.2K 103J CHIP R 10K	J 1/10W J 1/10W E1 J 1/10W
R171 R172 R173 R174 R175	RK73EB2B470J RK73EB2B102J RK73EB2B470J RK73EB2B102J RK73EB2B100J	CHIP R 47 J 1/8W CHIP R 1.0K J 1/8W CHIP R 47 J 1/8W CHIP R 1.0K J 1/8W CHIP R 10 J 1/8W	R309 RK73FB2A R310 RK73FB2A R311 RK73FB2A R312,313 RK73FB2A RX73FB2A	172J CHIP R 4.7K 102J CHIP R 1.0K 222J CHIP R 2.2K 223J CHIP R 22K	J 1/10W
R176 R177 R200,201 R203 R205,206	RK73EB2B4R7J RK73EB2B100J RK73FB2A622J RK73FB2A332J RK73FB2A102J	CHIP R 4.7 J 1/8W CHIP R 10 J 1/8W CHIP R 6.2K J 1/10W CHIP R 3.3K J 1/10W CHIP R 1.0K J 1/10W	R314 RK73FB2A/ R315 RK73FB2A/ R316 RK73FB2A/ R317 RK73FB2A/ R318 RK73FB2A/	153J CHIP R 15K 173J CHIP R 47K 562J CHIP R 5.6K	
R207 R208 R209 R210 R210	R92-2029-05 R92-2025-05 RK73FB2A393J RK73FB2A154J RK73FB2A184J	CHIP R 2.0K D 1/10W CHIP R 180 D 1/10W CHIP R 39K J 1/10W K1M2 CHIP R 150K J 1/10W K1M2 CHIP R 180K J 1/10W E1	R319 RK73EB2B2 R320 RK73FB2A2 R321 RK73FB2A3 R322 RK73FB2A4 R323 RK73FB2A4	393J CHIP R 39K 103J CHIP R 10K 580J CHIP R 68	J 1/8W J 1/10W J 1/10W J 1/10W J 1/10W
R211,212 R213 R214 R215 R216	RK73FB2A104J RK73FB2A683J RK73FB2A183J RK73FB2A753J RK73FB2A182J	CHIP R 100K J 1/10W CHIP R 68K J 1/10W CHIP R 18K J 1/10W CHIP R 75K J 1/10W E1 CHIP R 1.8K J 1/10W E1	R324 RK73FB2A4 R325 RK73FB2A2 R326 RK73FB2A3 R327 RK73FB2A3 R328 RK73FB2A3	222J CHIP R 2.2K 02J CHIP R 1.0K 01J CHIP R 100	J 1/10W E1
R217 R218,219 R220 R221 R222	RK73FB2A161J RK73FB2A103J RK73FB2A823J RK73FB2A153J RK73FB2A103J	CHIP R 160 J 1/10W E1 CHIP R 10K J 1/10W E1 CHIP R 82K J 1/10W E1 CHIP R 15K J 1/10W E1 CHIP R 10K J 1/10W E1	R329 RK73FB2AI R330 RK73FB2AI R331 RK73FB2AI R332 RK73FB2AI R333 RK73FB2AI	082J CHIP R 6.8K 02J CHIP R 1.0K 062J CHIP R 5.6K	J 1/10W
R223 R224 R225 R226 R231,232	RK73FB2A562J RK73FB2A103J RK73FB2A104J RK73FB2A103J RK73FB2A361J	CHIP R 5.6K J 1/10W E1 CHIP R 10K J 1/10W E1 CHIP R 100K J 1/10W E1 CHIP R 10K J 1/10W E1 CHIP R 360 J 1/10W	R334 RK73FB2A1 R334 RK73FB2A4 R335 RK73FB2A2 R336 RK73FB2A3 RK73FB2A3	73J CHIP R 47K 223J CHIP R 22K 513J CHIP R 51K	J 1/10W K1M2 J 1/10W E1 J 1/10W J 1/10W J 1/10W E1
R233,234 R235,236 R237,238 R239,240 R241,242	RK73FB2A223J RK73FB2A104J RK73FB2A153J RK73FB2A223J RK73FB2A820J	CHIP R 22K J 1/10W CHIP R 100K J 1/10W CHIP R 15K J 1/10W CHIP R 22K J 1/10W CHIP R 82 J 1/10W	R338 RK73FB2AS R339 RK73FB2AS R340 RK73FB2AS R341 RK73FB2AS VR1 R32-0212-	660J CHIP R 56 222J CHIP R 2.2K 331J CHIP R 330	J 1/10W E1 J 1/10W E1 J 1/10W E1 J 1/10W E1 J 1/10W E1 IABLE RESISTOR
R243,244 R245,246 R247,248 R249,250 R251,252	RK73FB2A361J RK73FB2A223J RK73FB2A104J RK73FB2A153J RK73FB2A223J	CHIP R 360 J 1/10W CHIP R 22K J 1/10W CHIP R 100K J 1/10W CHIP R 15K J 1/10W CHIP R 22K J 1/10W	W1 -3 R92-2052- W18 R92-2052- W18 -21 R92-2052- W19 -21 R92-2052- W22 -24 R92-2052-	CHIP R OCHIP R OCHIP R OCHIP R OCHIP R	J 1/10W K1M2 J 1/10W E1 J 1/10W M2 J 1/10W K1 J 1/10W E1
R253,254 R255 R256 R257-260 R262	RK73FB2A820J RK73FB2A103J RK73FB2A223J RK73FB2A472J RK73FB2A154J	CHIP R 82 J 1/10W CHIP R 10K J 1/10W CHIP R 22K J 1/10W CHIP R 4.7K J 1/10W CHIP R 150K J 1/10W	W24 R92-2052- PH1 T95-0231- D1 RM10ZLF D2 AM01Z		J 1/10W K1M2
R263 R264 R265-268 R301 R302	RK73FB2A751J RK73FB2A431J RK73FB2A223J RK73FB2A682J RK73FB2A222J	CHIP R 750 J 1/10W CHIP R 430 J 1/10W CHIP R 22K J 1/10W CHIP R 6.8K J 1/10W CHIP R 2.2K J 1/10W E1	D2 AM01Z D2 ERA15-01 UZL-6(M1) D4 UZL-9(L1) D5 UZ-11BS(E	DIODE ZENER DIODE ZENER DIODE	

K1: KDC-8007

M2: KDC-8008

E1: KDC-9050R

PARTS LIST

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnes dans le Parts No. ne sont pas fournis.

ELECTRIC UNIT (X25-781X-XX)

Ref No.	N e w	Parts No.	Description/Destinat	ion	Ref No.	Parts No.	Description/Destinat	tion
D6 D7 D8 D9 ,10		MA3220H UZL-11(M3) UZL-6(M1) DA204K 1SS133	ZENER DIODE ZENER DIODE ZENER DIODE DIODE DIODE		Q9 Q9 Q10 Q10 Q11	DTC144EK UN2213 DTA124EK UN2112 2SB1443	DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR TRANSISTOR	
D12 ,13 D12 ,13 D13 D13 D14		AM01Z ERA15-01 AM01Z ERA15-01 MA3047M	DIODE DIODE DIODE DIODE ZENER DIODE	K1M2 K1M2 E1 E1	Q12 Q12 Q13 Q14 Q14	2SC2412K 2SD601A 2SB1184 2SC2412K 2SD601A	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	
D15 ,16 D17 D17 D18 -21 D22		UZL-6(M1) DAN202K MA152WK UZMA6.2F DAN202K	ZENER DIØDE DIØDE DIØDE ZENER DIØDE DIØDE		Q17 Q18 Q18 Q21 Q21	2SB1443 2SC2412K 2SD601A 2SC2412K 2SD601A	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	
D22 D23 D30 D31 D50 ,51		MA152WK DA204K DA204K MA3068M DAN202K	DIODE DIODE DIODE ZENER DIODE DIODE	E1	Q22 ,23 Q24 -26 Q24 -26 Q27 Q28	2SA1037K 2SC2412K 2SD601A 2SB1443 2SA1037K	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	
050 ,51 052 053 ,54 053 ,54		MA152WK UZMA6.8F DAP202K MA152WA DAN202K	DIODE ZENER DIODE DIODE DIODE DIODE	E1	Q29 ,30 Q29 ,30 Q30 Q30 Q31	DTC114EK UN2211 DTC114EK UN2211 DTA124EK	DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR	K 1 M K 1 M E 1 E 1
055 060 060 061 061		MA152WK DAP202K MA152WA DAN202K MA152WK	DIODE DIODE DIODE DIODE	K1 K1	Q31 Q32 Q33 ,34 Q34 Q35 ,36	UN2112 2SA1037K 2SB1277(Q,R) 2SB1277(Q,R) 2SC2412K		K 1 M E 1
IC1 IC1 IC2 IC3 IC4		178016BGC519 178018BGC514 TDA7420 HD74HC27FP TDA7384A	MI-COM IC MI-COM IC ANALOGUE IC MOS-IC ANALOGUE IC	K1M2 E1	Q35 ,36 Q37 Q37 Q38 Q38	2SD601A DTA124EK UN2112 DTC144EK UN2213	TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR	
[05 [06 [07 [08 [09		TDA7435 M5237ML KKZ01F TC7660SEQA TC4W66F	ANALOGUE IC IC(VOLTAGE REGULATOR) CUSTOM IC ANALOGUE IC IC	K1E1 E1	Q39 Q39 Q40 Q40 Q41	DTC124EK UN2212 DTA124EK UN2112 DTC124EK	DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR	
C10,11 C12 C13 C14	1	NJM4565M-TE2 BA6219BFP-Y SAA6579T LA1145M 2SB1565F(E,F)	ANALOGUE IC ANALOGUE IC IC ANALOGUE IC TRANSISTOR	E1	Q41 Q42 Q42 Q50 Q50	UN2212 DTA124EK UN2112 DTC144EK UN2213	DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR	E 1 E 1
22 22 23 24 24		2SC2412K 2SD601A 2SA1037K DTC124EK UN2212	TRANSISTOR TRANSISTOR TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR		Q51 Q52 Q52 ,53 Q60 Q60	2SA1037K 2SK536 2SK536 DTC124EK UN2212	TRANSISTOR FET FET DIGITAL TRANSISTOR DIGITAL TRANSISTOR	E1 K1M E1
95 96 97		2SB1184 DTC114YK UN2214 2SB1443 2SD2396F40	TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR TRANSISTOR TRANSISTOR		961 961 962 962 964 -67	2SC2412K 2SD601A 2SC2412K 2SD601A 2SD2114K	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	K1M: K1M: E1 E1

K1: KDC-8007

M2: KDC-8008

E1: KDC-9050R

PARTS LIST

* New Parts

Parts without **Parts No.** are not supplied. Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

ELECTRIC UNIT (X25-781X-XX) K1:0-11 M2:0-22 E1:2-71 CD PLAYER UNIT (X32-4290-00)

Ref No.	N	Parts No.	Description/Destination			Ref No	N					Description/Destination		
THE INO.	w	raits IVU.	Description	Destination		Herivo	J.	w	i ai tə ivu.		Describe	- Desi	und	
Q70 ,71 Q70 ,71 Q72 Q72 Q74		DTC124EK UN2212 2SC2412K 2SD601A DTA124EK	DIGITAL TRANSIS DIGITAL TRANSIS TRANSISTOR TRANSISTOR DIGITAL TRANSIS	ST 0 R	E1	C31 C41 C42 C43 C44			CK73EB1C105K C92-1335-05 CK73EB1H104K CK73FB1H123K CK73FB1C104K	CHIP ELEC CHIP CHIP CHIP	TR © C C	1.0UF 4.7UF 0.10U 0.012 0.10U	F UF	K 16WV K K K
Q74 Q75 Q75 Q76 Q76		UN2112 2SC2412K 2SD601A DTC124EK UN2212	DIGITAL TRANSIS TRANSISTOR TRANSISTOR DIGITAL TRANSIS DIGITAL TRANSIS	STOR	E1 E1 E1	C45 C51 C52 C61 C63			CK73FB1H223KTA C92-0005-05 CK73FB1H103K CK73EB1C105K C92-0509-05	CHIP CHIP CHIP CHIP	-TAN C C	0.022 2.2UF 0.010 1.0UF 10UF		K 6.3WV K K 6.3WV
Q77 Q78 Q78 Q79 Q80		2SB1277(Q,R) DTC114TK UN2215 2SB1277(Q,R) DTB123YK	TRANSISTOR DIGITAL TRANSIS DIGITAL TRANSIS TRANSISTOR DIGITAL TRANSIS	STOR	E1 E1 K1	C65 ,6 C67 ,6 C71 ,7 C73 ,7 C75 -7	8 72 74		CK73FB1C104K C92-0004-05 CC73FCH1H101J CC73FCH1H121J CC73FCH1H270J	CHIP CHIP CHIP CHIP	-TAN C C	0.10U 1.0UF 100PF 120PF 27PF	F	K 16WV J J J
Q82 Q82		2SC2412K 2SD601A	TRANSISTOR TRANSISTOR		K1M2 K1M2	C79 ,8	30		CK73FB1H222K	CHIP	С	2200P	F	K
Q82 ,83 Q82 ,83 Q84		2SC2412K 2SD601A DTC114TK	TRANSISTOR TRANSISTOR DIGITAL TRANSIS	STOR	E1 E1	CN1 CN2			E40-9536-05 E40-9339-05		CABLE C			
Q84 Q85 Q85 Q86		UN2215 DTA144EK UN2113 2SC2412K	DIGITAL TRANSIS DIGITAL TRANSIS DIGITAL TRANSIS TRANSISTOR	TOR	E1	L1 L2 X1 X2			L40-1001-31 L79-0914-05 L78-0620-05 L78-0528-05	LC F	L FIXED ILTER NATOR NATOR	INDUCT	ØR(10UH)
Q86		2SD601A	TRANSISTOR		E1	R1 R2			RK73FB2A243J RK73FB2A183J	CHIP		24K 18K		1/10W 1/10W
TH1		NT732ATD33KJ	THERMISTOR		_	R3 R4			RK73FB2A154J RK73FB2A155J	CHIP	R	150K 1.5M	J J	1/10W 1/10W
A1 A1		W02-1523-05 W02-1524-05	FM/AM FRONT-END FM/AM FRONT-END		E1 K1M2	R5		1	RK73FB2A910J	CHIP		91	J	1/10W
			NIT (X32-4290-			R6 R7			RK73FB2A154J RK73FB2A155J	CHIP	R	150K 1.5M	J J	1/10W 1/10W
C1 ,2 C3 ,4 C5 C6		CK73EB1C105K C92-0509-05 CC73FCH1H220J CC73FCH1H020C	CHIP-TAN 10 CHIP C 22	OUF K OUF 6.1	3WV	R8 R9 R10 ,1	. 1	ł	RK73EB2B4R7J RK73EB2B100J RK73FB2A912J	CHIP CHIP CHIP	R	4.7 10 9.1K	J J J	1/8W 1/8W 1/10W
C7		CK73FB1C104K		10UF K		R12 R13			RK73FB2A562J RK73FB2A683J	CHIP		5.6K 68K		1/10W 1/10W
C8 C9 C10 C11 ,12		CK73EB1C105K CC73FCH1H101J CK73FB1H682K CK73FB1H222K	CHIP C 10 CHIP C 68	OUF K 10PF J 100PF K		R14 ,1 R16 R17	.5		RK73FB2A824J RK73FB2A223J RK73FB2A393J	CHIP CHIP CHIP	R	820K 22K 39K	J J	1/10W 1/10W 1/10W
C13 ,12		CK73FB1E273KTA		027UF K		R18 R19			RK73FB2A392J RK73FB2A333J	CHIP		3.9K 33K	J J	1/10W 1/10W
C14 C15 C16 C17		CK73FB1H472K CK73FB1E473KTA CC73FCH1H101J CK73FB1H222K	CHIP C 0. CHIP C 10	00PF K 047UF K 00PF J	ļ	R20 R21 R31			RK73FB2A104J RK73FB2A224J RK73FB2A102J	CHIP CHIP CHIP	R R	100K 220K	J J J	1/10W 1/10W 1/10W
C18		CC73FCH1H391J		OPF J		R32 R33			RK73FB2A104J RK73FB2A155J	CHIP		100K 1.5M		1/10W 1/10W
C19 ,20 C21 C22 C23		CK73FB1C104K C92-0509-05 CK73FB1C104K CK73FB1H102K	CHIP-TAN 10 CHIP C 0.	10UF K 10UF 6.1 10UF K	3 W V	R34 R35 R36			RK73FB2A333J RK73FB2A104J RK73FB2A111J	CHIP CHIP CHIP	R R	33K	J J	1/10W 1/10W 1/10W
C24		CK73FB1H223KTA		022UF K		R37 R38			RK73FB2A471J RK73FB2A224J	CHIP		470 220K	J J	1/10W 1/10W
C25 C26 C27		CK73FB1H123K CK73FB1C104K CC73FCH1H101J	CHIP C 0. CHIP C 10	012UF K 10UF K		R41 R42 R43			RK73FB2A101J RK73FB2A104J RK73FB2A101J	CHIP CHIP CHIP	R R	100 100K 100	J J	1/10W 1/10W 1/10W
C28 C29		CK73EB1C105K CK73FB1H102K		OUF K		R44			RK73FB2A102J	CHIP	R	1.OK	J	1/10W
												<u> </u>		

K1: KDC-8007

M2: KDC-8008

E1: KDC-9050R

PARTS LIST

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnes dans le Parts No. ne sont pas fournis.

CD PLAYER UNIT (X32-4290-00) MECHANISM ASSY (X92-3190-00)

Ref No.	N e w	Parts No.	Descript	ion/Destin	ation	Ref No	o.	N e w	Parts No.	CHANISM ASSY (X92-3190-00 Description/Destination
R45		RK73FB2A103J	CHIP R	10K J		Q6			2SA1037K	TRANSISTOR
R46 R47		RK73FB2A102J RK73FB2A103J	CHIP R	1.0K J 10K J	1/10W 1/10W				MECHANISM .	ASSY (X92-3190-00)
R48 -50 R51		RK73FB2A472J RK73FB2A101J	CHIP R CHIP R	4.7K J 100 J	1/10W 1/10W	2	2A 1B 2B	*	A10-4224-31 A10-4225-13 A11-0915-23	CHASSIS CHASSIS CALKING ASSY SUB CHASSIS CALKING ASSY
R52 R53 R54 R55 R56		RK73FB2A104J RK73FB2A101J RK73FB2A104J RK73FB2A101J RK73FB2A104J	CHIP R CHIP R CHIP R CHIP R CHIP R	100K J 100 J 100K J 100 J 100K J	1/10W 1/10W 1/10W	5 5 A 6	3B 2A 2A 2A 2A	* * * *	D02-0209-03 D10-3082-13 D10-4038-13 D10-3083-34 D10-3084-34	TURNTABLE PLATTER ARM ASSY ARM ASSY ARM ASSY
R57 R58 -64 R65 ,66 R67 R68		RK73FB2A472J RK73FB2A101J RK73FB2A472J RK73FB2A101J RK73FB2A104J	CHIP R CHIP R CHIP R CHIP R	4.7K J 100 J 4.7K J 100 J 100K J	1/10W 1/10W 1/10W	9 10 11	2B	* * * *	D10-3087-24 D10-3092-03 D10-3093-04 D10-3095-04 D10-3096-04	ARM ASSY SLIDER SLIDER ASSY SLIDER ASSY SLIDER ASSY
R69 R71 R72 R73 R74		RK73FB2A101J RK73FB2A752J RK73FB2A102J RK73FB2A333J RK73FB2A123J	CHIP R CHIP R CHIP R CHIP R	100 J 7.5K J 1.0K J 33K J 12K J	1/10W 1/10W 1/10W 1/10W 1/10W	13 14 15 16	1 A 1 A 2 A 1 B 1 B	* *	D10-3099-04 D10-3100-04 D10-4123-04 D10-4004-04 D10-4006-04	SLIDER ASSY SLIDER ASSY LEVER ASSY LEVER ASSY LEVER ASSY
R75 R76 R77 R78 R79		RK73FB2A273J RK73FB2A512J RK73FB2A393J RK73FB2A153J RK73FB2A202J	CHIP R CHIP R CHIP R CHIP R CHIP R	27K J 5.1K J 39K J 15K J 2.0K J		18 19 20 21	1 A 2 B 2 A	* *	D10-4007-04 D10-4008-04 D10-4009-03 D10-4010-04 D10-4011-24	LEVER LEVER LEVER LEVER
R80 R81 R82 R83 R91		RK73FB2A162J RK73FB2A273J RK73FB2A562J RK73FB2A561J RK73FB2A753J	CHIP R CHIP R CHIP R CHIP R CHIP R	1.6K J 27K J 5.6K J 560 J 75K J	1/10W	23 24 27 28	3 A 3 B 3 B 3 B	* *	D10-4013-04 D10-4013-04 D10-4050-04 D13-1229-13 D13-1230-14 D13-1231-04	ARM ASSY ARM RACK (GEAR) WORM
R92 R101,102 R103,104 R111-114 R115-118		RK73FB2A102J RK73FB2A241J RK73FB2A122J RK73FB2A513J RK73FB2A473J	CHIP R CHIP R CHIP R CHIP R CHIP R	1.0K J 240 J 1.2K J 51K J 47K J		30 31 32 33	3B 3B 3B 3B	* * * *	D13-1232-04 D13-1233-04 D13-1234-14 D13-1238-03 D13-1240-04	GEAR GEAR GEAR GEAR ASSY GEAR
R119-122 R123-126 R127,128 V1		RK73FB2A393J RK73FB2A683J RK73FB2A681J R92-2052-05 R92-2053-05	CHIP R CHIP R CHIP R CHIP R CHIP R	39K J 68K J 680 J 0 J 0 J	1/10W	35 36 37 38	3B 3B 1B	* * *	D13-1241-04 D13-1242-04 D13-1243-04 D13-1244-04	GEAR GEAR GEAR GEAR
51 ,2 53	*	S68-0822-05 S68-0823-05	PUSH SWITCH PUSH SWITCH				1B 2A		D13-1245-14 D13-1246-04	GEAR GEAR
01 ,2 IC1 IC2 IC3		DAN202K AN8806SB MN662724RPE M37471M8-368FP	DIODE ANALOGUE IC MOS-IC MI-COM IC			41 42 4 42 43 2	2B 2B 2B	* *	D13-1247-04 D13-1248-04 D13-1249-04 D14-0668-04	GEAR GEAR GEAR GEAR ASSY ROLLER
IC4 IC5 IC6 IC7		BA6790FP KKZO5F TA78L05F NJM5532MD 2SA1362(Y)	ANALOGUE IC CUSTOM IC IC(VOLTAGE R IC(OP AMP) TRANSISTOR	EGUL A T 0 R/	+5V)	47 48 49	1 A 3 B 2 B 3 B	*	D14-0670-04 D14-0674-04 D19-0613-14 D21-2228-04 D21-2229-04	ROLLER ROLLER LEAD SCREW SHAFT SHAFT
93 ,4 95		2SA1362(Y) DTC124EK	DIGITAL TRANS TRANSISTOR DIGITAL TRANS			52 2 53 1	A A B B B	*	D23-0925-04 D32-0614-04 D39-0223-05 D39-0224-05	RETAINER STØPPER DAMPER DAMPER

K1: KDC-8007

M2: KDC-8008

E1: KDC-9050R

PARTS LIST

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnes dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

MECHANISM ASSY (X92-3190-00)

Ref I	No.	N e w	Parts No.	Description/Destination
_			F09-1246-04	SHEET(M1)
60 61 62 63 64	2B 3A 3A 3A 3A	* * *	G01-2770-04 G01-2771-04 G01-2772-14 G01-2773-14 G01-2774-34	EXTENSION SPRING EXTENSION SPRING EXTENSION SPRING EXTENSION SPRING EXTENSION SPRING
65 66 67 68 69	3B 3A	* * *	G01-2775-04 G01-2776-14 G01-2777-14 G01-2824-14 G01-2844-04	TORSION COIL SPRING TORSION COIL SPRING TORSION COIL SPRING COMPRESSION SPRING EXTENSION SPRING
70 71 72 73	2A 2B 2A 2A	* *	G02-1231-04 G02-1232-04 G02-1241-24 G02-1248-14	FLAT SPRING FLAT SPRING FLAT SPRING FLAT SPRING
75 76 77 78 79	3A 2B	*	J11-0613-03 J19-4678-13 J19-4679-14 J21-7684-03 J21-7686-03	CLAMPER HOLDER HOLDER MOUNTING HARDWARE MOUNTING HARDWARE
80 81 82 83	3B 3A	* * *	J21-7690-03 J31-1032-04 J84-0060-05 J90-0757-12	MOUNTING HARDWARE COLLAR FLEXIBLE PRINTED WIRING BOARD GUIDE
A B C D E	2A 1B 2B 2A 3A	* *	N09-4158-05 N09-4172-05 N09-4187-05 N38-2020-46 N82-2006-46	MACHINE SCREW (M1.7X2.5にき,カフ) TAPPING SCREW (2X3.5,Cタイト) MACHINE SCREW (M1.7X4,ヒラ,カフ°) PAN HEAD MACHIN SCREW BINDING HEAD TAPTITE SCREW
FG	1B 2B		N19-2023-04 N19-2058-04	FLAT WASHER FLAT WASHER
M1 M2 PU1	3B 3B 2B		T42-0764-04 T42-0763-04 T25-0209-05	DC MOTOR DC MOTOR OPTICAL PICKUP HEAD

K1: KDC-8007

M2: KDC-8008

E1: KDC-9050R

SPECIFICATIONS

FM tuner section (KDC-8007/8008 only) Frequency range (Frequency step) 8007	LW tuner section (KDC-9050R only) Frequency range (Frequency step) 153kHz \sim 281kHz Usable sensitivity (S/N=20dB)
Channel space selection	CD section
8007	Laser diode
8008	Digital filter (D/A)
Usable sensitivity (S/N=30dB) 9.3dBf (0.8 μ V/75 Ω) Quieting sensitivity (S/N=50dB) 15.2dBf (1.6 μ V/75 Ω)	D/A converter
Frequency response (±3.0dB) 30Hz~15kHz	Spindle speed
Signal to Noise ratio (MONO)	Frequency response (±1dB)10~20kHz
Selectivity (dB)≧ 80dB (±400kHz)	Total harmonic distortion
Stereo separation (1kHz)	Signal to Noise ratio (1kHz)
	Dynamic range
FM tuner section (KDC-9050R only)	Chanel separation
Frequency range (Frequency step)	
87.5MHz~108.0MHz (50kHz)	Audio section
Usable sensitivity (S/N=26dB) 0.7μ V/75 Ω	Preout level (mV)/Load 400mV/10kΩ
Quieting sensitivity (S/N=46dB)	Preout impedance 80Ω
Frequency response (±3.0dB)	Amp power
Selectivity (dB) ≥ 80dB (±400kHz)	Max
Stereo separation (1kHz)	(8007/8008 only)
otoroo coparation (TKT12)	DIN45324, +B=14.4V 25W x 4 (9050R only)
AM tuner section (KDC-8007/8008 only)	Tone action
Frequency range (Frequency step)	Bass100Hz±10dB
8007 530kHz~1700kHz (10kHz)	Treble 10kHz±10dB
8008 531kHz~1611kHz (9kHz)	
Channel space selection	General
8007 10kHz fix	Operating voltage 14.4V (11~16V allowable)
8008	Current consumption 10A at rated power
Usable sensitivity (S/N=20dB) 28dB μ (25 μ V)	Installation size (W x H x D) 182 x 53 x 165 (mm)
MW tuner section (KDC-9050R only)	7-3/16 x 2-1/16 x 6-1/2 (inch)
Frequency range (Frequency step)	Weight (net)
	KENWOOD follows a policy of continuous advancements in develop-
Usable sensitivity (S/N=20dB)30μV	ment. For this reason specifications may be changed without notice.

KENWOOD CORPORATION

14-6, Dogenzaka 1-chome, Shibuya-ku, Tokyo, 150 Japan

KENWOOD SERVICE CORPORATION

P.O. Box 22745, 2201 East Dominguez Street, Long Beach, CA90801-5745, U.S.A.

KENWOOD ELECTRONICS CANADA INC. 6070 Kestrel Road, Mississauga, Ontario, Canada L5T 158

KENWOOD ELECTRONICS LATIN AMERICA S.A.
P.O. Box 55-2791, Piso 6, Plaza Chase, Cl. 47 y, Aquilino de la Guardia, Panama, Republic of Panama

KENWOOD ELECTRONICS BRASIL LTDA. Avenida Indianópolis, 628, 04062-001 Planalto Paulista, São Paulo-SP-Brasil

KENWOOD ELECTRONICS UK LIMITED

Kenwood House, Dwight Road, Watford, Herts, WD1 8EB, United Kingdom

KENWOOD ELECTRONICS DEUTSCHLAND GMBH

Mechelsesteenweg 418, B-1930 Zaventem, Belgium

KENWOOD ELECTRONICS FRANCE S.A. 13, Boulevard Ney, 75018 Paris, France KENWOOD ELECTRONICS BELGIUM N.V. KENWOOD ELECTRONICS ITALIA S.p.A.

KENWOOD IBÉRICA S.A.

KENWOOD ELECTRONICS AUSTRALIA PTY. LTD. (A.C.N. 001 499 074)

8 Figtree Drive, Australia Centre, Homebush, N.S.W. 2140, Australia

KENWOOD & LEE ELECTRONICS LTD.

1, Metroplaza, 223 Hing Fong Road, Kwai Fong, N.T., Hong Kong

KENWOOD ELECTRONICS GULF FZE P.O. Box 61318, Jebel Ali, Dubai, U.A.E.

KENWOOD ELECTRONICS (THAILAND) CO., LTD.

573/111 Soi Ramkhamhaeng 39, Ramkhamhaeng Road, Wangthonglang, Bangkapi, Bangkok, 10310 Thailand

KENWOOD ELECTRONICS SINGAPORE PTE. LTD.

KENWOOD ELECTRONICS (MALAYSIA) SDN BHD #4.01 Level 4, Wisma Academy, Lot 4A, Jalan 19/1, 46300 Petaling Jaya, Selangor Malaysia